

STUDIO 10 enclosure size recommended space



9.2' height required for (Studio 10) size enclosure – or enough room to swing driver, whichever is the greater



Ideal room width 11.5' - 13' so you can hit centre of screen without swing hitting side walls of your room. Otherwise means hitting 'off-centre.'



Suggested minimum room depth for SkyTrak & SkyTrak+ is 17'

